

TUFLOC

INSTALLATION INSTRUCTIONS

Universal Mount Gun Rack



Congratulations and thank you for your recent purchase of the **TUFLOC** gun rack system. Esmet has designed and manufactured the highest quality products for over sixty-five years and we are confident that you will be a satisfied Tufloc product owner.

This manual includes simple step-by-step instructions to install, operate and maintain your gun rack. Please contact the factory if you have any installation or operation questions.

Universal Mount

CAUTION : This mount style is not suitable for vehicles that have side curtain air bags

1. Temporarily mount weapon rack and gun to extension bar.
2. Determine best location of weapon rack system in vehicle, extend extension bar and mark holes in headliner.
3. Remove gun from extension bar.
4. Drill (6) 1/8" mounting holes in headliner and secure extension bar using #10 x 1 Pan Head Self Tap Sheet Metal Screws. **WARNING DO NOT PUNCTURE VEHICLE ROOF.**
5. Attach and insulate the red / black wires (supplied) to the corresponding red / black wires on the lockhead. Insure that the wires are not pinched as they are routed behind the channel toward the most convenient power and grounding source.
6. Mount weapon rack according to diagram below.
 - Large lockheads can be custom fit for weapons. Simply raise or lower the adjustment plate by loosening or tightening the screw.
 - The tension of the adjustable foam clip can be adjusted by tightening or loosening the bolts.

