

Medeco Cylinder Lubrication

Approved Products:

Medeco® KeyLube™ 2.0 Multi-purpose Lubricant
PX-KYLUB2-03 (5.25 oz.) Aerosol can with spray tube

Sandstrom® Poxylube® CP-200 Air Drying Solid Film Lubricant
Poxylube CP-200 (4.5 oz.) Aerosol can with spray tube

Synco® Super Lube® Dri-Film Lubricant
Super Lube Dri-Film (11 oz.) Aerosol can with spray tube

Where to Order:

Medeco KeyLube
Medeco Customer Service 1-800-839-3157

Poxylube CP-200
<http://www.sandstromproducts.com> or 1-800-747-1084

Super Lube Dri-Film
<http://www.super-lube.com> or 1-800-253-LUBE (5823)

How to Lubricate:

No other lubricants should be used with Medeco Key Lube. Locks that are dirty or oily should be cleaned with an electrical contact cleaner such as the one made by LPS or those available at Radio Shack stores. Extremely dirty or oily locks may have to be completely disassembled as part of the cleaning procedure. It is recommended that only Medeco Factory Certified Locksmiths take apart Medeco cylinders.

- ✓ Shake can well and with opening on white nozzle pointing away from face, insert the red plastic spray tube into the end of the white nozzle.
- ✓ Place the red plastic spray tube against the keyhole and press down on the white nozzle using three, one second bursts of spray.
- ✓ Allow the lubricant to penetrate the cylinder 10 seconds before inserting the key. Wipe the face of the cylinder with a rag if over-spray coats the face of the lock.

How Often to Lubricate:

Frequency of lubrication depends on location of the cylinder, weather conditions and amount of use. A lock installed on an interior door that is only used a couple times a day should be lubricated once a year. A lock installed on the exterior entrance door of an apartment with several hundred tenants and freezing weather conditions should be lubricated at least 4 times a year or anytime the key is difficult to insert or turn.

Warranty:

Medeco is not responsible for damage to the lock caused by foreign matter other than Medeco approved lubricants or by accident, theft, misuse, abuse, or abnormal use or conditions.