

TUFLOC

INSTALLATION INSTRUCTIONS

TufBox Light




Congratulations and thank you for your recent purchase of this TUFLOC product. Esmet has designed and manufactured the highest quality products for over sixty-five years and we are confident that you will be a satisfied Tufloc product owner.

This manual includes simple step-by-step instructions to install and operate your TufBox Light. Please contact the factory if you have any installation or operation questions.

TufBox Light Installation

- The interior light for the TufBox is supplied with double-sided tape which will allow the light to be placed almost anywhere inside the drawer.
- With the light turned on (preferably in a dark environment) determine the best mounting location inside the TufBox. Consider the following:
 - This location will vary based on where the user wants the light directed.
 - Contents inside of the TufBox such as dividers and equipment should also be a consideration when determining this location.
 - The best location to illuminate the entire box is located directly in the center on the underside of the cabinet.
 - **If drawer light is not centered on the cabinet there will not be enough clearance for the drawer to work properly.**
- **Prior to installation, make sure there is enough space to be able to slide the light off the back plate to replace the batteries.**
- Remove coating from one side of the double-sided tape and adhere it to the back plate of the light.
- Remove coating from other side of double-sided tape and secure light to box.



**Bottom View of Cabinet
(Drawer Removed for clarity)**